

Data sheet Karta katalogowa Scheda di dati Fiche Technique Datenblatt

EN

Training effect:

Option 1: Effective strengthening the upper parts of muscle

Option 2: Stretching

How to use:

Option 1: Pull-rod: Hold the handle bar and avoiding swinging pull the body to the chest height. Then slowly lower.

Option 2: Stretching: Rest your foot on the rung at waist height. Follow skłony torso foot level and feet on the ground.


A total safety and funcionality of equipment can only be kept when the inspections are made on regular basis. A subject of control should be potencial damages and use. Always observe the maintance and instalation guide.


This device is designed for people over 1.4 m tall.

For single person use only. Maximum user's weight 120 kg.

Made followed the PN-EN 16630:2015-06 norm

Made in Poland















Maintenance manual Instrukcja konserwacji Manuel de maintenance Manuale di manutenzione Wartungshandbuch

EN

A inspection is carried out as follows:

Routine inspection:

Visual inspection device is intented to detect visible damage and risks that could arise for reasons such as: misuse, vandalism or weather conditions.

NOTE 1 For outdoor fitness installed in areas with intensive use of equipment, and also in areas characterized to frequent damage caused by vandalism, may be required daily inspection.

NOTE 2 During the inspection routine and operational should pay attention to: cleanliness, level ground state of the ground, exposed (mobile) foundations, sharp edges, missing parts, excessive used (mobile and disperse the parts), structural strength of construction.

Operational control:

More accurate than a routine inspection of facilities for checking the functionality and stability of exercise equipment. You should do this every 1 to 3 months according to guidance of manufacturer

Main annual inspection:

Control of defining the overall condition for safe exploating of equipment (main annual review).

NOTE 3 Main annual inspection may need to dig or decompose (spin) of individual equipment or their parts.

The annual inspection should be performed by the manufacturer or an authorized repairer Outdoor Fitness Center. Submissions annual inspection the following address: fitness@outdoorfitness.pl

Failures

In the absence of damage or exploating of the device must be immediately replaced or repaired. If this is not possible, secure the unit before use. Contact the site Oudtoor Fitness Center: fitness@outdoorfitness.pl.

Use only original spare parts. Repair and replacement of parts may only make the manufacturer or its authorized representative.











Installation manual Instrukcja instalacji Manuel d'installation Manuale di installazione Installationshandbuch













Impact Area
Strefa opadku
Zone d'Impact
Area de Impacto
Fallraum


12,5 m²

Required surface: Lawn

Wymagana powierzchnia: Trawnik Erforderliche Oberfläche: Rasen

Superficie richiesta: Prato

Требуемая поверхность: Газон














Concrete pad
Fundament betonowy
Dalle béton
Solera de Hormigón
Beton Bodenplatte















Dimensions in centimeters



















Dimensions in centimeters













PRF-2