

Data sheet Karta katalogowa Scheda di dati Fiche Technique Datenblatt

EN

Training effect:

Upper parts of muscle Trains. It improves the efficiency of the upper limbs and muscles of the shoulder girdle. Ogólorozwojowe excellent exercise.

How to use:

- 1. Catch the small wheel with both hands and rotate to the left or right.
- 2. Catch the big wheel with one hand and rotate to the left or right.


A total safety and funcionality of equipment can only be kept when the inspections are made on regular basis. A subject of control should be potencial damages and use. Always observe the maintance and instalation guide.


This device is designed for people over 1.4 m tall.

For single person use only. Maximum user's weight 120 kg.

Made followed the PN-EN 16630:2015-06 norm

Made in Poland

















Maintenance manual Instrukcja konserwacji Manuel de maintenance Manuale di manutenzione Wartungshandbuch

EN

A inspection is carried out as follows:

Routine inspection:

Visual inspection device is intented to detect visible damage and risks that could arise for reasons such as: misuse, vandalism or weather conditions.

NOTE 1 For outdoor fitness installed in areas with intensive use of equipment, and also in areas characterized to frequent damage caused by vandalism, may be required daily inspection.

NOTE 2 During the inspection routine and operational should pay attention to: cleanliness, level ground state of the ground, exposed (mobile) foundations, sharp edges, missing parts, excessive used (mobile and disperse the parts), structural strength of construction.

Operational control:

More accurate than a routine inspection of facilities for checking the functionality and stability of exercise equipment. You should do this every 1 to 3 months according to guidance of manufacturer

Main annual inspection:

Control of defining the overall condition for safe exploating of equipment (main annual review).

NOTE 3 Main annual inspection may need to dig or decompose (spin) of individual equipment or their parts.

The annual inspection should be performed by the manufacturer or an authorized repairer Outdoor Fitness Center. Submissions annual inspection the following address: fitness@outdoorfitness.pl

Failures

In the absence of damage or exploating of the device must be immediately replaced or repaired. If this is not possible, secure the unit before use. Contact the site Oudtoor Fitness Center: fitness@outdoorfitness.pl.

Use only original spare parts. Repair and replacement of parts may only make the manufacturer or its authorized representative.











Installation manual Instrukcja instalacji Manuel d'installation Manuale di installazione Installationshandbuch













Impact Area
Strefa upadku
Zone d'Impact
Area de Impacto
Fallraum

11,0 m²

Required surface: lawn, bark mulch, woodchip,sand, gravel

Wymagana nawierzchnia: gleba, trawnik, mulcz z kory, drobno pokrojone

kawałki drewna, piasek, źwir

Requis de surface: la pelouse, le paillis d'écorce,


copeaux de bois, sable, gravier

Superficiale necessaria: erba, pacciame di corteccia, finemente tritato

pezzi di legno, sabbia, ghiaia

Erforderliche Oberflächen: Gras, Rindenmulch, fein gehackt

Holzstücke, Sand, Kies














Concrete pad
Fundament betonowy
Dalle béton
Solera de Hormigón
Beton Bodenplatte


















Dimensions are in centimeters


4xM16



4xM16














Starmax - Outdoor Fitness Center Rycerska 3 st, 83-050 Bakowo, Poland tel. +48 884 000 884, +48 600 273 852 fitness@outdoorfitness.pl










Footing plan
Plan fundamentowania
Implanation
Implanación
Fundamentplan



Dimensions are in centimeters

